



USER MANUAL

GNSS EQUIPMENT

NGR-3000

NOTICE TO USERS

- Thanks for purchasing this product NGR-3000 GNSS equipment.
- The copyright of this manual is owned by the manufacturer, NEW SUNRISE CO., LTD (NSR). Prior written permission is required for copying or reproducing the manual or part of the manual.
- The software version in your product may be some different from that described in this manual. Such differences will not affect the performance of the product. NSR reserves the right of continuous improvement on products both in software and in hardware without any prior notice.
- NSR will assume no responsibility for the damage caused by improper use or modification of the product or claims of loss of profit by a third party.
- NSR does not make any representations or warranties (implied or otherwise) regarding the accuracy and completeness of this document and shall in no event be liable for any loss of profit or any commercial damage, including but not limited to special, incidental, consequential, or other damage.
- Please read this manual carefully to ensure proper use before installation and use of the product.
- Please keep the manual for your future reference.




MODIFY RECORD

No.	Modify by	Date	Paragraph	Version	Reason
1	Q/A	2017/06/14		01	First edition
2	Q/A	2017/08/15		02	Add navigation function
3	Q/A	2017/09/29		03	Generally modified
4	Q/A	2019/03/31	All	04	Software update
5	Q/A	2021/07/16	All	05	Software update
6	Q/A	2022/06/13	All	06	Software update
7	Q/A	2025/07/07	All	07	Some modification
8	Q/A	2025/12/11	All	08	Software update

VERSION COMPARISON TABLE

Manual Version	Program Version	Remarks
20250707_07	v2.07, 2025/06/09	
20251211_08	v2.08, 2025/12/05	

SAFETY INSTRUCTIONS FOR THE OPERATOR

	<p>Warning Keep away from heat source or direct sunshine.</p>
	<p>Prohibition Don't open the equipment. Only qualified personnel should work inside the equipment. Don't disassemble or try to modify the equipment.</p>
	<p>Dangerous Turn off the power immediately when smoke or fire is emitted.</p>

SAFETY INSTRUCTIONS FOR THE INSTALLER




	<p>Warning Connect the earthing cord to ship's body. Observe the compass safe distance to prevent deviation of an onboard magnetic compass.</p>
	<p>Prohibited Don't open the equipment unless you have fully understood the structure and circuits of the equipment. Only qualified personnel should work inside the equipment. Don't disassemble or try to modify the equipment.</p>
	<p>Dangerous Turn off the power at power distribution board before installation.</p>

TABLE OF CONTENTS

1. PRODUCT FEATURES	1
2. OPERATIONAL OVERVIEW	2
2.1 Control Description	2
2.2 Power ON/OFF	2
2.3 Adjust Dimmer and Contrast	3
2.4 Basic Menu Operation	3
2.5 How to Enter Character Data	4
2.6 Display Modes	4
2.6.1 Data display	5
2.6.2 Plotter display	6
2.6.3 Highway display	8
2.6.4 Compass display	8
2.6.5 Satellite display	9
3. NAVIGATION PLANNING	10
3.1 Register Waypoints	10
3.1.1 Insert a new waypoint	11
3.1.2 Edit a waypoint	11
3.1.3 Delete a waypoint	12
3.2 Route Planning	13
3.2.1 Edit a route	13
3.2.2 Forward navigation	14
3.2.3 Reverse navigation	14
3.2.4 Create a new route	14
3.2.5 Delete a route	15
3.3 Stop the Navigation by the Current Route	15
4. NOTICE	16
4.1 XTE (Cross Track Error) Alarm	16
4.2 Speed Alarm	17
4.3 Arrival Alarm and Anchor Watch Alarm	17
4.4 Track Record	19
4.5 ETA-SOG	20
4.6 Notice Audio	20
5. MENU SETTING	21
5.1 GNSS Setting	21
5.1.1 GNSS mode	21
5.1.2 2D/3D	21
5.1.3 Geodetic datum	22
5.1.4 RAIM	22
5.1.4.1 RAIM	22

5.1.4.2 RAIM level.....	23
5.1.5 Beacon/SBAS.....	23
5.1.6 Smoothing.....	24
5.2 System Setting.....	24
5.2.1 Key buzzer.....	25
5.2.2 LCD/Key dimmer.....	25
5.2.3 Day/Night.....	25
5.2.4 Unit.....	25
5.2.5 Offset & Time Zone.....	26
5.3 Alert.....	26
5.4 Diagnostics.....	28
5.4.1 Program version.....	28
5.4.2 LCD test.....	28
5.4.3 Factory test.....	29
5.4.4 Factory default.....	29
5.4.5 GNSS monitoring.....	30
5.4.6 RTCM monitor.....	30
6. INSTALLATION.....	31
6.1 Installation of Main Unit.....	31
6.2 Installation of Antenna Unit.....	31
6.3 Cabling.....	31
6.3.1 Power connection.....	32
6.3.2 Interfaces.....	32
6.3.3 Alert interface.....	32
6.3.4 Grounding.....	33
6.4 Initial Settings.....	33
6.4.1 Language setting.....	33
6.4.2 Sentence setting.....	34
6.4.2.1 Sentence.....	34
6.4.2.2 Baud rate.....	36
6.4.2.3 NMEA version.....	36
APPENDIX I MENU TREE.....	37
APPENDIX II TECHNICAL SPECIFICATIONS.....	38
APPENDIX III SENTENCE DESCRIPTION.....	40
APPENDIX IV INSTALLATION DRAWING.....	47

1. PRODUCT FEATURES

NGR-3000 is an IMO GNSS equipment of NSR's new generation, compatible with GPS, Beidou, Glonass, and Galileo systems.

NGR-3000 GNSS equipment consists of a display unit and an antenna unit. The highly sensitive GNSS equipment tracks up to 50 satellites simultaneously. It ensures optimum accuracy in the determination of vessel position, course and speed.

The main features of NGR-3000 are:

- Comprehensive navigation data displays.
- Alarms: Loss of Position, loss of differential signal, HDOP Exceeded.
- Menu-driven operation.
- 7-inch, color LCD, touch screen operation with adjustable brightness.
- 3 GNSS data outputs, BAM/INS input/output.
- A DGNSS beacon receiver (external) may be connected to NGR-3000 to add DGNSS function.

The product meets the requirements of relevant IMO and IEC regulations & standards, including IMO MSC.112 (73), MSC.302 (87), IEC 61108-1, IEC 62923-1, IEC 62923-2 and IEC 62288, etc.

EQUIPMENT LIST:

Scope of Supply				
No.	Name	Q'ty	Part No.	Description
1	NGR-3000 Main Unit	1	N992530	
2	NGA100 GNSS Antenna	1	N581010/ N581020	Cable length 10m or 20m
3	Installation Materials			
3.1	Antenna Mount Pole	1	N563030	
3.2	Steel Tie	2	N170400	
3.3	Accessories	1		
4	Options			
4.1	DGNSS Upgrading Kit	1	N502561	
4.2	NFB700A Flush Mount Brackets	1	N561070	
4.3	NND-100 NMEA distributor	1	N995710	
4.4	NND-200 NMEA distributor	1	N995720	

2. OPERATIONAL OVERVIEW

2.1 Control Description

The GNSS equipment can be operated by the key & knob on panel or touch-screen.



When operating with the knob, turn the knob to select an item on the screen and press the knob to confirm the selection.

Panel Button	Description
	Turn to select an item. Press to confirm the selection or input.
	Power ON/OFF. To power OFF, press and hold this button for more than 3 seconds.
	Press to change the LCD brightness.
Touch-screen Button	Description
	Enter to display different modes.
	Acknowledge the current alert.
	Change day/night mode.

2.2 Power ON/OFF

- Turn on the power

Press the **PWR** button to turn on the power. Usually, it will take about 45 seconds to find its position when turned on for the very first time.

- **Turn off the power**

Press and hold down the **PWR** button for 3 seconds until the screen goes blank.

2.3 Adjust Dimmer and Contrast

There are two ways to adjust the brightness and contrast of the LCD.

- Adjust the brightness in the **[SYSTEM SETTING]** by clicking **[LCD/KEY DIMMER]**.

[SYSTEM SETTING]		
GN- 3D	31°26.9200'N 120°31.6616'E	UTC 2025-07-07 01:48:41
KEY BUZZER		OFF
LCD/KEY DIMMER		11
DAY/NIGHT		DAY
UNIT		kn. NM
OFFSET & TIME ZONE		
←		
SET LCD/KEY DIMMER : 1 - 13		


- Press the **DIM** button to adjust the brightness.

Note:

When the power is turned off, the last status of brightness is stored. Therefore, when the power is turned on next time, the screen will display with the last brightness before powered off.

2.4 Basic Menu Operation

Most operations of your unit are carried out through the menu. If you get lost in operation, press the **PWR** button to return to the **MAIN** menu. Please refer to the complete MENU TREE in the Appendix.

DATA	ACK	DATA		
		HDOP	RAIM	RAIM LEVEL
		0.8	Safe	100m
PLOTTER				TIME
HIGHWAY		° 26. 9241 ' N		2025-12-05 03:32:54 UTC
COMPASS		° 31. 6626 ' E		LAST FIX
SATELLITE				2025-12-05 03:32:54 UTC
SETTINGS		SOG		SV NUM:
		0.0°	00.0 kn	GPS: 13
SOLUTION DATA				

2.6.1 Data display


The **DATA** display is the default display mode of the equipment.

Basic data will be displayed in this mode, including position in latitude and longitude, course, speed, date and time.

NGR-3000 takes about 45 seconds to find the position when turned on for the very first time.

Thereafter, it takes about 30 seconds to find the position each time the power is turned on.


After fixing, the accurate position (in latitude and longitude) appears on the display. If the position could not be found, loss of position will appear in the alert column.



No.	Item	Symbol	Remark
①	Fix Mode	GP-D3D	See Note 1.
②	Datum	WGS84/PZ90	
③	Position in LAT & LON		
④	Course over Ground	COG	
⑤	Alert Column		Click to enter the alert list when an alert exists.
⑥	Time	UTC/LMT	GNSS Time
⑦	Final Fixing Time	LAST FIX	
⑧	Quantity of Satellites Being Tracked	SATELLITE	


No.	Item	Symbol	Remark
⑨	Horizontal Dilution Of Precision	HDOP	
⑩	Receiver Autonomous Integrity Monitoring	RAIM	Safe/unsafe/caution/off
⑪	Accuracy Level for RAIM		10-100m
⑫	Speed over Ground	SOG	

Note 1:





2.6.2 Plotter display

The **PLOTTER** display traces own ship's track, shows position, course, speed, and sets display range.




Click to change display






You may increase or decrease the display range on the Plotter display. The range in the Plotter display is available among 0.02, 0.05, 0.1, 0.2, 0.5, 1, 2, 5, 10, 20, 40, 80, 160 and 320 nautical miles.


- 1) Click the **OPERATE** button. The pop-up menu appears.
- 2) Click **[ZOOM IN]** or **[ZOOM OUT]** to select the desired range.
- 3) Click on any blank space to finish.



Press **[SHIP]** to return.




Press [ADD MOB] to add a waypoint named “MOB.XXX” based on the ship/cursor location.




2.6.3 Highway display

The **HIGHWAY** display provides a 3-D view of own ship's route toward the destination. Navigation data is also shown.




2.6.4 Compass display

The **COMPASS** display provides the course with the ship's speed, and position.



2.6.5 Satellite display

The **SATELLITE** display shows satellites currently tracked, together with the strength of receiving signals. Only the enabled GNSS system can view satellite signals. Enable the satellite system in [GNSS Settings]->[GNSS Mode].




3. NAVIGATION PLANNING


Typically, a trip from one place to another involves several course changes, requiring a series of waypoints which you navigate to, one after another. The sequence of waypoints leading to the ultimate destination is called a route. NGR-3000 can automatically advance to the next waypoint on a route, so you do not have to change the destination waypoint repeatedly. NGR-3000 can store 30 routes and each route may include up to 100 waypoints.

There are two ways to enter Waypoint and Route.

- (1) Click [MENU]-[SETTINGS]-[NAVIGATION] to open the menu.



- (2) Click [PLOTTER] in [MENU], then click [WAYPOINT] / [ROUTE] in [OPERATE] to open the menu.



3.1 Register Waypoints

Click [NAVIGATION]-[WAYPOINT LIST] to open the waypoint list.

[NAVIGATION]								
GP- 3D	31°26.9210'N	120°31.6615'E	UTC 2022-05-13 08:46:47					
<table border="1"> <tr><td>WAYPOINT LIST</td></tr> <tr><td>ROUTE LIST</td></tr> <tr><td>NOTICE SETTING</td></tr> <tr><td>ASSISTANCE</td></tr> <tr><td>←</td></tr> </table>				WAYPOINT LIST	ROUTE LIST	NOTICE SETTING	ASSISTANCE	←
WAYPOINT LIST								
ROUTE LIST								
NOTICE SETTING								
ASSISTANCE								
←								
Display Waypoint List								

TOTAL:024 PAGE: 1 / 4 [WAYPOINT LIST]											
GP- 3D	31°26.9210'N	120°31.6615'E	UTC 2022-05-13 08:47:02								
>>	024	31°26.920'N MOB.024	120°31.661'E 2022-05-13 08:29								
	023	31°30.993'N POINT023	120°44.444'E 2022-05-13 08:22								
	022	31°33.588'N POINT022	120°37.905'E 2022-05-13 08:22								
	021	31°31.929'N POINT021	120°31.267'E 2022-05-13 08:22								
	020	31°29.376'N POINT020	120°27.973'E 2022-05-13 08:22								
	001	33°28.879'N WPT. .002	119°37.660'E 2022-04-21 09:11								
<table border="1"> <tr><td>ADD</td></tr> <tr><td>DELETE</td></tr> <tr><td>EDIT</td></tr> <tr><td>Page ↓</td></tr> <tr><td>Page ↑</td></tr> <tr><td>GO TO</td></tr> <tr><td>SEND</td></tr> <tr><td>←</td></tr> </table>				ADD	DELETE	EDIT	Page ↓	Page ↑	GO TO	SEND	←
ADD											
DELETE											
EDIT											
Page ↓											
Page ↑											
GO TO											
SEND											
←											
Add One Waypoint Of Current Position											

- 1) Click to select the desired waypoint.
- 2) Select [ADD], [DELETE] or [EDIT] desired.

3.1.1 Insert a new waypoint

Create a new waypoint with the position as own ship's current position. The new waypoint will be inserted before the waypoint that is selected by the current cursor.

3.1.2 Edit a waypoint

Edit the selected waypoint.

TOTAL:024 PAGE: 1 / 4 [WAYPOINT EDIT]									
GP- 3D	31°26.9210'N	120°31.6616'E	UTC 2022-05-13 08:47:27						
>>	024	31°26.920'N MOB.024	120°31.661'E 2022-05-13 08:29						
	023	31°30.993'N POINT023	120°44.444'E 2022-05-13 08:22						
	022	31°33.588'N POINT022	120°37.905'E 2022-05-13 08:22						
	021	31°31.929'N POINT021	120°31.267'E 2022-05-13 08:22						
	020	31°29.376'N POINT020	120°27.973'E 2022-05-13 08:22						
	001	33°28.879'N WPT. .002	119°37.660'E 2022-04-21 09:11						
<table border="1"> <tr><td>LAT</td></tr> <tr><td>LON</td></tr> <tr><td>NAME</td></tr> <tr><td>ID</td></tr> <tr><td>CONFIRM</td></tr> <tr><td>CANCEL</td></tr> </table>				LAT	LON	NAME	ID	CONFIRM	CANCEL
LAT									
LON									
NAME									
ID									
CONFIRM									
CANCEL									

ADD a waypoint

Add a waypoint to the route from the route list.

Click **[ADD]** to add the current position as a new waypoint to the route.

The screen will change to **[WAYPOINT LIST]** display.

RENAME the route

Click **[RENAME]**, the pop-up menu appears.

The route name can be up to 17 characters.

The operation is as follows:

- 1) Click **[RENAME]** to rename the desired route.
- 2) Click the character among A-Z, 0-9 desired.
- 3) Click **[✓]** to finish.

DELETE a waypoint

Click **[DELETE]** to delete the selected waypoint from the route.

3.2.2 Forward navigation

Click **[FORWARD]** in **[ROUTE LIST]** menu to start navigation forward. The screen will switch to the **PLOTTER** page.

TOTAL: 002		PAGE:1/1		[ROUTE LIST]	
GP- 3D	31°26.9211'N	120°31.6620'E	UTC	2022-05-13	09:05:18
ID	NAME	PTS	DISTANCE		
>> 2	ROUTE - NO.00002	4	15.9 nm	EDIT	
1	RTU001YHJKJHGVC	15	1033.8 nm	FORWARD	
				REVERSE	
				ADD	
				DELETE	
				Page ↓	
				Page ↑	
				←	

3.2.3 Reverse navigation

Click **[REVERSE]** to start navigation in reverse. The screen will switch to the **PLOTTER** page.

3.2.4 Create a new route

Click **[ADD]** to add a new route just after the current route.

TOTAL: 003 PAGE:1/1 [ROUTE LIST]				
GP- 3D 31°26.9211'N 120°31.6619'E		UTC 2022-05-13 09:10:06		
ID	NAME	PTS	DISTANCE	
>> 3	ROUTE - NO.00003	0	0.0 nm	EDIT
2	ROUTE - NO.00002	4	15.9 nm	FORWARD
1	RTU001YHJKJHGVC	15	1033.8 nm	REVERSE
				ADD
				DELETE
				Page ↓
				Page ↑
				←

3.2.5 Delete a route

Click **[DELETE]** to delete the selected route from the route list. Click “YES” to confirm the operation.


TOTAL: 003 PAGE:1/1 [ROUTE LIST]				
GP- 3D 31°26.9212'N 120°31.6619'E		UTC 2022-05-13 09:10:28		
ID	NAME	PTS	DISTANCE	
>> 3	ROUTE - NO.00003	0	0 nm	EDIT
2	ROUTE - NO.00002	9	9 nm	FORWARD
1	RTU001YHJKJHGVC	8	8 nm	REVERSE
				ADD
				DELETE
				Page ↓
				Page ↑
				←

CONFIRM

NO

YES

3.3 Stop the Navigation by the Current Route




Click **[PLOTTER]** in **[MENU]**, then click **[STOP]** to stop the navigation by the current route. The route is cleared on the **PLOTTER** display.

4. NOTICE



Important note: All these navigational alarms (XTE, SPEED, ARV, ANC) should be switched off on SOLAS- (or IMO-) compliant ships.

Select [SETTINGS]-[NAVIGATION]-[NOTICE SETTING] to open the menu.



4.1 XTE (Cross Track Error) Alarm

The XTE alarm warns you by an internal buzzer when own ship is off its intended route.



[NOTICE SETTING]	
GN-D3D 31°26.9197'N 120°31.6610'E UTC 2022-06-22 07:45:37	
XTE ALARM	01.50 nm
SPEED ALARM	HIGH OFF LOW OFF
ARV/ANC ALARM	ARV 02.00 nm ANC OFF
TRACK	SPACE 02.00 nm
123	00.00 nm
0 1 2 3 4 5 6 7 8 9	
N S E W	

- 1) Click the value field to edit.
- 2) Click the digits among 0-9 until the desired digit is obtained.
- 3) When the value is set to 0, the alarm will be turned off.

4.2 Speed Alarm

The speed alarm is activated when the ship's speed is higher (or lower) than the set value.

[NOTICE SETTING]	
GN-D3D 31°26.9198'N 120°31.6612'E UTC 2022-06-22 07:46:06	
XTE ALARM	01.50 nm
SPEED ALARM	HIGH OFF LOW OFF
ARV/ANC ALARM	ARV 02.00 nm ANC OFF
TRACK	SPACE 02.00 nm
123	20.0 kn
0 1 2 3 4 5 6 7 8 9	
N S E W	

LOW: Alarm is activated when the speed is lower than the speed set in the field.

HIGH: Alarm is activated when the speed is higher than the speed set in the field.

- 1) Click the **HIGH/LOW** speed value to edit.
- 2) Click the digits among 0-9 until the desired digit is obtained.
- 3) When the value is set to 0, the alarm will be turned off.


4.3 Arrival Alarm and Anchor Watch Alarm

You may activate the arrival alarm or the anchor watch alarm but they cannot be activated together.

[NOTICE SETTING]	
GN-D3D 31°26.9198'N 120°31.6612'E UTC 2022-06-22 07:46:25	
XTE ALARM	01.50 nm
SPEED ALARM	HIGH OFF LOW OFF
ARV/ANC ALARM	ARV 02.00 nm ANC OFF
TRACK	SPACE 02.00 nm
ETA-SOG	10.0 kn
NOTICE AUDIO	ON
←	

● Arrival Alarm

The arrival alarm informs you that own ship is approaching a destination waypoint. The area that defines an arrival zone is that of a circle which you approach from the outside of the circle. The alarm will be activated if own ship enters the circle.




- 1) Click the **ARV** alarm value to edit.
- 2) Click the digits among 0-9 until the desired digit is got.
- 3) Turn the knob to move the cursor to the next digit to edit.
- 4) When the value is set to 0, the alarm will be turned off.

The alarm range is (0.01-99.99 nm).

● Anchor Watch Alarm

The anchor watch alarm sounds to warn you that own ship is moving beyond the set area.



Before setting the anchor watch alarm, set the current position as the destination.

- 1) Click the ANC alarm value to edit.
- 2) Click the digits among 0-9 until the desired digit is obtained.
- 3) Turn the knob to move the cursor to the next digit to edit.
- 4) When the value is set to 0, the alarm will be turned off.

The alarm range is (0.01-99.99 nm).

NOTE:

The anchor watch alarm and arrival alarm are combined to serve a route. After a route is finished while the destination is arrived at, keep the navigation on the route while setting ANC. The anchor watch starts.

4.4 Track Record

Click [TRACK] to set the interval of every two recorded dots.

[NOTICE SETTING]	
GN-D3D 31°26.9199'N 120°31.6612'E UTC 2022-06-22 07:46:48	
XTE ALARM	01.50 nm
SPEED ALARM	HIGH OFF LOW OFF
ARV/ANC ALARM	ARV 02.00 nm ANC OFF
TRACK	SPACE 02.00 nm
ETA-SOG	10.0 kn
NOTICE AUDIO	ON
←	

If **OFF** is selected, the track will not be recorded.

If **SPACE** is selected, the track will be recorded every a certain distance which can be configured.

If **AUTO** is selected, the track will be recorded every minute or every certain distance which can be configured, whichever is reached first.

4.5 ETA-SOG

When forwarding a route, but $SOG < 0.4$ kn, ETA will be calculated according to this SOG. The default is 10.0 kn

[NOTICE SETTING]	
GN-D3D 31°26.9198'N 120°31.6611'E UTC 2022-06-22 07:47:08	
XTE ALARM	01.50 nm
SPEED ALARM	HIGH OFF LOW OFF
ARV/ANC ALARM	ARV 02.00 nm ANC OFF
TRACK	SPACE 02.00 nm
ETA-SOG	10.0 kn
NOTICE AUDIO	ON
←	
Set up a custom SOG for computing ETA when SOG<0.4 kn.	

4.6 Notice Audio

Set whether an audible alarm is required for Notice.

5. MENU SETTING

5.1 GNSS Setting

Click [MENU]-[SETTINGS]-[GNSS SETTING] to open the menu as follows.

[GNSS SETTING]			
GP-D3D	31°26.9213' N	120°31.6587' E	UTC 2025-12-05 04:49:27
GNSS MODE			
2D / 3D		AUTO	
GEODETTIC DATUM		WGS84	
RAIM			
BEACON/SBAS		SBAS	
SMOOTHING			
←			

It includes **GNSS MODE**, **2D/3D**, **GEODETTIC DATUM**, **RAIM**, **BEACON/SBAS** and **SMOOTHING** settings.

5.1.1 GNSS mode

There are four GNSS systems that can be selected: GPS, BDS, GLONASS and GALILEO. BDS and GLONASS can not be enabled at the same time.

GNSS MODE SELECT			
GN-D3D	31°26.9211' N	120°31.6590' E	UTC 2025-12-05 04:49:01
GPS ✓			
BDS ✓			
GLONASS			
GALILEO			
←			

5.1.2 2D/3D

Select 2D or 3D fix mode.

[2D / 3D]	
GP- 3D	31°26.9201'N 120°31.6617'E UTC 2022-05-13 11:58:57
2D	
3D	
AUTO	
←	

5.1.3 Geodetic datum

Totally, there are three systems to be selected: WGS84, PZ-90 and CGCS2000.

[GEODETIC DATUM]	
GP- 3D	31°26.9201'N 120°31.6617'E UTC 2022-05-13 11:58:45
WGS84	
PZ90	
CGCS2000	
←	

5.1.4 RAIM

5.1.4.1 RAIM

RAIM (Receiver Autonomous Integrity Monitoring) can be set to **ON** or **OFF**.

When set to **ON**, RAIM will display SAFE, UNSAFE or CAUTION in the following conditions:

- **Conditions for the "safe" state**

The result of the integrity calculation by means of RAIM will be stated as "safe", if the integrity calculation can be performed with a confidence level above 95 % for the selected accuracy level and RAIM calculates the probable position error to be within the selected accuracy level.

This generally requires at least 5 "healthy" satellites available and in a robust geometry, i.e., the worst 4 satellite geometry is still suitable for navigation.

- **Conditions for the "caution" state**

The "caution" status will be used to indicate:

- Insufficient information to reliably calculate with a confidence level above 95 % for the selected accuracy level, or
- The probability of false alarms >5 %, or
- The probability of not detecting an error condition >5 %.

Those conditions may occur if an insufficient number of satellites are available, for example, 4 or 5 with 2 satellites "close" together in azimuth and elevation, causing the geometry to degrade to the point that the RAIM calculation becomes unreliable. Note that the resulting accuracy based on 4 or 5 satellites in use may be within the selected accuracy level, but the RAIM algorithm cannot verify it.

- **Conditions for the "unsafe" state**

The "unsafe" status will be used if the integrity calculation is performed with a confidence level above 95 % for the selected accuracy level, and RAIM calculates the probable position error exceeding the selected accuracy level. Note that also here a robust geometry is required to reach this confidence level. The "unsafe" state can be reached when satellite range errors degrade the navigation solution, causing the resulting accuracy to be outside the selected accuracy level.

5.1.4.2 RAIM level

RAIM level can be set between 10-100m.

[RAIM]	
GP- 3D 31°28.5212 N 121°39.9341 E	UTC 2019-03-21 15:53:41
RAIM	ON
RAIM LEVEL	100m
←	

5.1.5 Beacon/SBAS

The system will detect the DGNSS signal when [BEACON] is selected. If no DGNSS signal is coming, a warning "DGNSS Lost" will be raised.

[GNSS SETTING]		D
GP- 3D	31°26.9216'N 120°31.6623'E	UTC 2022-05-13 09:41:44
GNSS MODE	GPS	
2D / 3D	AUTO	
GEODETTIC DATUM	WGS84	
RAIM		
BEACON/SBAS	BEACON	
SMOOTHING		
←		
When no BEACON connected, [BEACON] will cause [DGNS Lost].		

5.1.6 Smoothing

Change the COG and SOG averages to adjust the smoothness.

[SMOOTH SETTING]		
GP- 3D	31°26.9207'N 120°31.6611'E	UTC 2022-05-13 10:49:29
SOG	OFF	
COG	OFF	
DRIVING MODE	SEA	
←		
SET SOG SMOOTHING [OFF/AUTO/1-9]		

5.2 System Setting

Click [MENU]-[SETTINGS]-[SYSTEM SETTING] to open the menu as follows.

[SYSTEM SETTING]		
GN- 3D	31°26.9199'N 120°31.6615'E	UTC 2025-07-07 01:47:28
KEY BUZZER	OFF	
LCD/KEY DIMMER	11	
DAY/NIGHT	DAY	
UNIT	kn, NM	
OFFSET & TIME ZONE		
←		
SET KEY BUZZER ON/OFF		

It includes **KEY BUZZER**, **LCD/KEY DIMMER**, **DAY/NIGHT**, **UNIT** and **OFFSET & TIME ZONE** items.

5.2.1 Key buzzer

Key buzzer can be turned off so that the operation is not heard.

5.2.2 LCD/Key dimmer


Dimmer can be adjusted either by **DIM** button or set in the menu.

[SYSTEM SETTING]		
GN- 3D	31°26.9200' N 120°31.6616' E	UTC 2025-07-07 01:48:41
KEY BUZZER	OFF	
LCD/KEY DIMMER	11	
DAY/NIGHT	DAY	
UNIT	kn, NM	
OFFSET & TIME ZONE		
←		
SET LCD/KEY DIMMER : 1 - 13		

5.2.3 Day/Night

Change the display mode between **DAY** and **NIGHT**. For example:

[SYSTEM SETTING]		
GN-D3D	31°26.9197' N 120°31.6617' E	UTC 2025-07-07 01:52:30
KEY BUZZER	OFF	
LCD/KEY DIMMER	4	
DAY/NIGHT	NIGHT	
UNIT	kn, NM	
OFFSET & TIME ZONE		
←		
CHANGE DISPLAY MODE DAY/NIGHT		

You can also click the  icon in the upper right corner of the main screen to change the display between day mode and night mode.

5.2.4 Unit

Unit can be set as **kn**, **NM** or **km/h**, **km**.

[SYSTEM SETTING]	
GN- 3D	31°26.9200'N 120°31.6617'E UTC 2025-07-07 01:48:56
KEY BUZZER	OFF
LCD/KEY DIMMER	11
DAY/NIGHT	DAY
UNIT	kn. NM
OFFSET & TIME ZONE	
←	
SET SPEED and RANGE UNIT	

5.2.5 Offset & Time Zone

[TIME MODE]: Time can be set as **UTC** or **LMT** in **TIME MODE**.

[TIME ZONE]: Set time zone from **-13:00** to **+13:00**

[LATITUDE OFFSET]: Set the latitude offset to add to the calculation of the position.

[LONGITUDE OFFSET]: Set the longitude offset to add to the calculation of the position.

[ANT HEIGHT]: Set the height of the GNSS antenna.

[OFFSET & TIME ZONE]	
GP- 3D	31°26.9204'N 120°31.6615'E UTC 2022-05-13 11:34:05
TIME MODE	UTC
TIME ZONE	+00:00
LATITUDE OFFSET	00.0000'N
LONGITUDE OFFSET	00.0000'E
ANT HEIGHT	020 m
←	
SET TIME MODE UTC/LMT	

5.3 Alert

List of all alerts that could be generated:

ID	Ins	Cat	Prio	Escal	Resp	Alert Title	Alert description
3056	1	B	C	/	/	HDOP exceeded	HDOP > 4.0 check antenna
3015	2	B	W	W	Yes	Loss of position	Loss of position check antenna
3055	3	B	W	W	Yes	DGNSS Lost*	Loss of differential signal
3012	4	B	W	W	Yes	Integrity status	Accuracy is unsafe check antenna
3062	5	B	W	W	YES	System fault	GNSS module malfunctioned

Ins: Instance of an alert;

Prio: Alert priority (W – Warning, C – Caution);


Cat: Alert category;

Escal: W – An unacknowledged warning will be repeated as a warning after 4 minutes;

Resp: Transfer responsibility.

*: “DGNSS Lost” takes effect when BEACON is selected.


When an alert occurs, the buzzer sounds (except for a caution) and the title of the alert appears at the bottom of the display. Click on the bottom to enter the alert list.



Alert mark description:

MARK	PRIORITY	STATE
←	WARNING	ACTIVE-UNACKNOWLEDGED
✘		ACTIVE-SILENCED
!		ACTIVE-ACKNOWLEDGED
→		ACTIVE-RESPONSIBILITY TRANSFERRED
✓		RECTIFIED-UNACKNOWLEDGED
!	CAUTION	ACTIVE

Click [MENU]-[SETTINGS]-[ALERT] to open the [ALERT] screen, it shows all currently alerts. Time is synchronized when GNSS is fixed, and not synchronized when GNSS is not fixed.



“>”: Point to the currently selected alert, click the alert to select.

[ACK]: Acknowledge the alert selected.

[MUTE]: Make all alerts silent for 30 seconds.

[VIEW]: View the details of the alert selected, as shown on the right.

[←]: Back to the upper menu.

[PWR]: Short-press the button to return to the main screen.

[ALERT VIEW]	
NO FIX	31°26.9075'N 120°31.6662'E UTC 2025-12-05 05:43:01
ID	3015 : 2
CATEGORY	B
PRIORITY	WARNING
STATE	ACTIVE-UNACKNOWLEDGED
DESCRIPTION	Loss of position Loss of position check antenna
←	
1/3 3015 Loss of position	

5.4 Diagnostics

Click [MENU] - [SETTINGS] - [DIAGNOSTICS] to check the software version, keypad and LCD for proper operation, etc.

[SETTINGS]	
GP- 3D	31°26.9204'N 120°31.6612'E UTC 2022-05-13 11:44:23
GNSS SETTING	
NAVIGATION	
ALERT	
SYSTEM SETTING	
DIAGNOSTICS	
MAINTENANCE	
←	
CARRY OUT SELF TEST	

5.4.1 Program version


Select [PROGRAM VERSION] item to check the software version, etc.

[DIAGNOSTICS]	
GP- 3D	31°26.9203'N 120°31.6612'E UTC 2022-05-13 11:44:40
PROGRAM VERSION	
LCD TEST	
FACTORY TEST	
FACTORY DEFAULT	
GNSS MONITOR	
RTCM MONITOR	
←	

5.4.2 LCD test

LCD TEST is used for testing the screen.

Click [LCD TEST] to enter the test screen, and turn the knob continuously to test the LCD.
Press the knob to exit.



5.4.3 Factory test

It is designed to test whether the key, knob and touch-screen are working or not, etc.
Click [FACTORY TEST] to enter the following view.

[FACTORY TEST]	
GP- 3D 31°26.9200'N 120°31.6611'E	UTC 2022-05-13 11:45:11
KEY	DIM :
KNOB	LEFT : RIGHT: ENT :
TOUCH	1 A: B: C:
BEACON IN	--
INS IN	--
←	
Press EXIT 3 times to exit	

KEY test: Press the **DIM** key.

KNOB test: Turn the knob to the left and right, then press it.


TOUCH test: Touch the corner of the screen. The box corresponding to the item will be filled with blue color.

If everything is good, **OK** icon will appear.

5.4.4 Factory default

FACTORY DEFAULT is to return the system to factory default settings.

Select [FACTORY DEFAULT] item in [DIAGNOSTICS] menu, then click “YES” to confirm the operation.




NOTE:

The navigation settings and GNSS settings will be restored to factory default, while the waypoints and routes registered remain unchanged.

5.4.5 GNSS monitoring

It's to check the GNSS data appearing on output ports.



5.4.6 RTCM monitor

When [BEACON/SBAS] in [GNSS SETTING] is set to BEACON, DGPS beacon input will be checked by NGR-3000.

6. INSTALLATION

6.1 Installation of Main Unit

The main unit can be installed on a tabletop, on the overhead, or in a panel (optional flush mounting brackets required). Refer to the drawings at the end of this manual for installation instructions. When selecting a mounting location, keep in mind the following points:

- Locate the unit away from exhaust pipes and vents.
- The mounting location should be well ventilated.
- Mount the unit where shock and vibration are minimal.
- Locate the unit away from equipment that generates electromagnetic fields, such as a motor or generator.
- Allow sufficient maintenance space at the sides and rear of the unit and leave sufficient slack in cables, to facilitate maintenance and servicing.
- Observe the following compass safe distances to prevent deviation of a magnetic compass. Standard compass, 0.2 m. Steering compass, 0.15 m.

6.2 Installation of Antenna Unit

Install the antenna unit by referring to the antenna installation drawings at the end of this manual. When selecting a mounting location for the antenna unit, keep in mind the following points:

- Do not cut the antenna cable.
- Select a location out of the radar beam. The radar beam will obstruct or prevent the reception of the GNSS signal.
- The location should be well away from a VHF/UHF antenna. GNSS equipment is interfered with by a harmonic wave of a VHF/ UHF antenna.
- There should be no obstruction within the line-of-sight to the satellites. Objects within line-of-sight to a satellite, for example, a mast, may block reception or prolong acquisition time.
- Mounting the antenna unit as high as possible keeps it free from interfering objects and water spray, which can interrupt reception of GNSS satellite signal if the water freezes.
- If the antenna cable is to be passed through a hole that is not large enough to pass the connector, you may unfasten the connector. Refasten it after running the cable through the hole.

6.3 Cabling

6.3.1 Power connection

PIN NO.	DESCRIPTION	TYPE
13	PWR (+24V)	DC Power
14	PWR (0V)	

The power cable with a rated capacity of 3A should be used. The pin definition for the connector is shown above.

Suggest using the 3A Power Supply Unit (DC 24V output).

6.3.2 Interfaces

PIN NO.	DESCRIPTION	TYPE
1	BEACON IN+	RTCM SC-104 V2.3
2	BEACON IN	
3	GNSS OUT 1+	IEC 61162-1/ IEC 61162-2
4	GNSS OUT 1-	
5	GNSS OUT 2+	IEC 61162-1/ IEC 61162-2
6	GNSS OUT 2-	
7	GNSS OUT 3+	IEC 61162-1/ IEC 61162-2
8	GNSS OUT 3-	
9	BAM OUT+	IEC 61162-1/ IEC 61162-2
10	BAM OUT-	
11	BAM IN+	IEC 61162-1/ IEC 61162-2
12	BAM IN-	
13	PWR (+24V)	DC Power
14	PWR (0V)	

[Beacon IN] is used to receive the differential signal from DGPS beacon.

[GNSS OUT] is used to output position data.

[BAM IN/OUT] is used to communicate with CAM.

The default baud rate is 4800 bps, which can also be changed among 4800/ 9600 / 19200 / 38400 bps.

6.3.3 Alert interface

There is one alert interface (IEC 61162-1/IEC 61162-2) for BAM.

PIN NO.	DESCRIPTION	TYPE
9	BAM OUT+	IEC 61162-1/ IEC 61162-2
10	BAM OUT-	
11	BAM IN+	IEC 61162-1/ IEC 61162-2
12	BAM IN-	

The alert list is described in Section 5.3.

6.3.4 Grounding


Ground the unit as follows to prevent interference:

- The ground wire should be 1.25mm² or larger.
- The ground wire should be as short as possible.


6.4 Initial Settings

This equipment can output navigation data to external equipment, in NMEA 0183 format. For example, it can output position data to a radar or echo sounder.

Initial settings are done in the menu of **[MAINTENANCE]**.



A password is required to enter **[MAINTENANCE]** menu.



6.4.1 Language setting

[LANGUAGE]: Change language (ENGLISH/中文/ Español).

6.4.2 Sentence setting

For each GNSS data output, the following items can be configured.

- **Data sentences:**

The following sentences are available: GBS, GNS, GGA, DTM, RMC, VTG, ZDA, GSA, XTE, WPL, BOD, RTE, GLL, APB, VLW, GFA, GRS, GST, GSV, RMB, BWC, HDT. When selecting sentences, the load rate needs to be kept below 100%. Each sentence can be set to be sent once every 1/2/5/10 seconds.

- **NMEA version**

There are five versions to be selected: NMEA1.5, NMEA2.0, NMEA2.3, IEC61162 Ed4 and IEC61162 Ed5.

- **Baudrate**

It can be 4800/9600/19200/38400bps.

6.4.2.1 Sentence

Click [MAINTENANCE]-[SENTENCE SETTING], the following menu appears.

[OUTPUT SENTENCE]		
GP- 3D 31°26.9196'N 120°31.6616'E	UTC 2022-05-13	11:46:49
GNSS OUT 1 & BEACON IN	IEC61162 Ed5	4800 BPS
GNSS OUT 2	IEC61162 Ed5	4800 BPS
GNSS OUT 3	IEC61162 Ed5	4800 BPS
INS/BAM IN & OUT	IEC61162 Ed5	4800 BPS
TALKER ID	GP	
←		

Click the ports to set the sentence. For example:

[SENTENCE SETTING]	
GP- 3D 31°26.9205'N 120°31.6617'E	UTC 2022-05-13 11:53:05
SENTENCE	
BAUDRATE	4800 BPS
VERSION	IEC61162 Ed5
←	
Select the Sentence need output	

Click each sentence continuously to choose 1s/2s/5s/10s. "--" means no output.

[OUTPUT SENTENCE]					
GP- 3D	31°26.9197'N	120°31.6614'E	UTC	2025-07-07	01:59:05
GBS	--	XTE	--	GRS	--
GNS	--	WPL	1 s	GST	--
GGA	1 s	BOD	--	GSV	--
DTM	1 s	RTE	1 s	RMB	--
RMC	1 s	GLL	1 s	BWC	--
VTG	1 s	APB	--	HDT	--
ZDA	1 s	VLW	--	←	
GSA	--	GFA	--	Load Rate:	91%

Data sentence description

- ACN: Equipment is operating normally, or for supervision of a connection between two units.
- ALC: Cyclic alert list. The cyclic alert list transmission shall never stop. When all alerts are in normal state, the cyclic alert list is empty, i.e. number of alert entries is 0.
- ALF: Report an alert condition and the alert state of a device. An ALF message shall be published for an alert each time the alert information in this sentence changes and on alert request (see ALC - Cyclic alert list).
- GNS: Fix data for GPS, GLONASS.
- GBS: Support Receiver Autonomous Integrity Monitoring (RAIM).
- GGA: GPS position fixing condition (time of fix, latitude, longitude, receiving condition, number of satellites used, DOP).
- HBT: The sentence is transmitted at regular intervals specified in the corresponding equipment standard. The repeat interval may be used by the receiving unit to set the time-out value for the connection supervision.
- RMC: Generic navigational information (UTC time, latitude, longitude, ground speed, true course, day, month, year).
- VTG: Actual track and ground speeds.
- ZDA: UTC time (day, month, year).
- DTM: Datum reference.
- GSA: GNSS receiver operating mode, satellites used in the navigation solution reported by the GGA 2148 or GNS sentences, and DOP values.
- RTE: Waypoint identifiers, listed in order with the starting waypoint first, for the identified route.
- BWC: Bearing and distance to waypoint - Great circle.
- RMB: Recommended minimum navigation information.
- XTE: Cross-track error, measured.
- WPL: Latitude and longitude of the specified waypoint.
- HDT: Heading true.

NOTE 1: By default, GNS, GBS, GGA, RMC, VTG, ZDA and DTM are selected.

NOTE 2: Click [TALKER ID], you can modify the Talker ID of the output sentence.

6.4.2.2 Baud rate

Select each of the four outputs to configure the baud rate.

The default baud rate of all ports is 4800bps.

Click BAUDRATE continuously until a desired rate is shown.

[SENTENCE SETTING]	
GP- 3D 31°26.9200' N 120°31.6619' E	UTC 2022-05-13 11:57:36
SENTENCE	
BAUDRATE	4800 BPS
VERSION	IEC61162 Ed5
←	
Set baudrate [4800/9600/19200/38400]	

The baud rate can be selected among 4800/9600/19200/38400bps.

6.4.2.3 NMEA version


Select each of the four outputs to configure the NMEA version.

Click VERSION continuously until the desired one is shown.

[SENTENCE SETTING]	
GP- 3D 31°26.9201' N 120°31.6619' E	UTC 2022-05-13 11:58:07
SENTENCE	
BAUDRATE	4800 BPS
VERSION	IEC61162 Ed5
←	
Set output sentence version	

The NMEA version can be selected among NMEA 1.5 / NMEA 2.0 / NMEA 2.3 / IEC61162 Ed4 / IEC61162 Ed5.

APPENDIX I MENU TREE



APPENDIX II TECHNICAL SPECIFICATIONS

● GNSS equipment

No	Item	Description
1	Receiving System	GPS, BDS, Glonass, Galileo
2	Rx signal and Frequency	GPS L1 C/A (1575.42 MHz) Glonass L1 C/A (1598.0625 ~ 1609.3125 MHz) BeiDou B1I (1561.098 MHz) Galileo E1 (1575.42 MHz)
3	Position Accuracy	less than 10m (GPS), less than 5m(DGPS), 95% of the time, horizontal dilution of position (HDOP) ≤ 4
4	SOG Accuracy	<0.1kn
5	Tracking Velocity	999 kts
6	Position-fixing Time	Cold start: 45 seconds, Warm start: 30 seconds
7	Position Update Interval	1 second
8	RAIM Indicators	Safe, Unsafe, Caution, N/A, off
9	Route	Up to 30
10	Waypoint	Up to 3000

● DISPLAY SECTION

No	Item	Description
1	Display	7-inch, color LCD, touch screen operation
2	Fix Mode	GPS, Glonass, BDS, Galileo or combined
3	Alerts	Loss of position and differential signals, HDOP > 4
4	Display Modes	Data, Plotter, Highway, Compass, Satellite
5	Track Plotter Display	0.02 to 320nm, 14 steps
6	Navigation Alarm	Arrival and Anchor Watch XTE, Speed
7	Satellite Information	Satellite number, Elevation, Signal level

- **INPUT/OUTPUT DATA**

No	Item	Description
1	GNSS Output	NMEA0183, totally 3 ports, baud rate 4800 / 9600 / 19200 / 38400 bps
	Version	NMEA1.5, NMEA2.0, NMEA2.3, IEC61162 Ed4, IEC61162 Ed5
	Sentences	ALF, DTM, GBS, GNS, GGA, GSA, RMC, VTG, ZDA, etc.
2	Beacon In	DGPS RTCM 10402.3
3	BAM/Ins In	ACN, HBT
4	BAM/Ins Out	ALC, ALF, HBT, ARC

- **POWER SUPPLY**

DC 24V (range 12~36V): 0.4A~0.5A

- **ENVIRONMENT CONDITION**

No	Item	Description
1	Ambient Temperature	Antenna Unit: -25°C to +70°C Display Unit: -15°C to +55°
2	Relative Humidity	95% at 40°C
3	IP Grade	Antenna Unit: IP66 Display Unit: IP22
4	Compass Safe Distance	Standard compass: 0.2m, Steering compass: 0.15m


- **OTHERS**

No	Item	Description
1	Size	145(H) x 264(W) x 83(D) mm
2	Weight	About 1.25kg (main unit)

APPENDIX III SENTENCE DESCRIPTION

ACN – Alert command


\$--ACN,hhmmss.ss,aaa,x.x,x.x,c,a*hh <CR><LF>



1. Time
2. Manufacturer's mnemonic code
3. Alert Identifier
4. Alert Instance, 1 to 999999
5. Alert command, A, Q, O or S
6. Sentence status flag

ALC - Cyclic alert list

\$--ALC,xx,xx,xx,x.x,aaa,x.x,x.x,x.x,.....,aaa,x.x,x.x,x.x*hh <CR><LF>




1. Total number of sentences for this message, 01 to 99
2. Sentence number, 01 to 99
3. Sequential message identifier, 00 to 99
4. Number of alert entries
5. Alert entry 1
6. Additional Alert entries
7. Alert entry n

Each entry identifies a certain alert with a certain state. It is not allowed that an alert entry is split between two ALC sentences.


- 3. Alert identifier
- 4. Alert instance, 1 to 999999
- 5. Refused alert command, A, Q,O or S

HBT – Heartbeat supervision sentence




- 1. Configured repeat interval
- 2. Equipment status
- 3. Sequential sentence identifier

HDT - Heading true



- 1. Heading, degrees true

DTM - Datum reference




- 1. Local datum WGS84 = W84
 WGS72 = W72
 SGS85 = S85
 PE90 = P90
 BDCS = C00
 User defined = 999
 IHO datum code
- 2. Local datum subdivision code
- 3. Lat offset, min, N/S
- 4. Lon offset, min, E/W
- 5. Altitude offset, m

6. Reference datum
- WGS84 = W84
 - WGS72 = W72
 - SGS85 = S85
 - PE90 = P90
 - BDCS = C00

GSA - GNSS DOP and active satellites


\$--GSA,a,x,xx,xx,xx,xx,xx,xx,xx,xx,xx,xx,xx,xx,x,x,x,x,x,h*hh<CR><LF>



1. Mode: M = manual, forced to operate in 2D or 3D mode
A = automatic, allowed to automatically switch 2D/3D
2. Mode: 1 = fix not available, 2 = 2D, 3 = 3D
3. ID numbers of satellites used in solution
4. PDOP
5. HDOP
6. VDOP

GBS - GNSS satellite fault detection

\$--GBS,hhmmss.ss,x,x,x,x,x,xx,x,x,x,x,x,h,h*hh <CR><LF>




1. UTC time of the GGA or GNS fix associated with this sentence
2. Expected error in latitude
3. Expected error in longitude
4. Expected error in altitude
5. ID number of most likely failed satellite
6. Probability of missed detection for most likely failed satellite
7. Estimate of bias on most likely failed satellite

8. Standard deviation of bias estimate
9. GNSS System ID
10. GNSS Signal ID

GLL - Geographic position - Latitude/longitude


\$--GLL,llll.ll,a,yyyy.yy,a,hhmmss.ss,A,a*hh<CR><LF>



1. Latitude, N/S
2. Longitude, E/W
3. UTC of position
4. Status A=data valid V=data invalid
5. Mode indicator

GNS - GNSS fix data


\$-- GNS,hhmmss.ss,llll.ll,a,yyyy.yy,a,c--c,xx,x.x,x.x,x.x,x.x,x.x,a *hh<CR><LF>



1. UTC of position
2. Latitude, N/S
3. Longitude, E/W
4. Mode indicator
5. Total number of satellites in use, 00-99
6. HDOP
7. Antenna altitude, m, re: mean-sea-level (geoid)
8. Geoidal separation, m
9. Age of differential data
10. Differential reference station ID
11. Navigational status indicator

VTG - Course over ground and ground speed


\$--VTG,x.x,T,x.x,M,x.x,N,x.x,K,a*hh<CR><LF>



1. Course over ground, degrees true
2. Course over ground, degrees magnetic
3. Speed over ground, knots
4. Speed over ground, km/h
5. Mode indicator

GGA -Global positioning system (GPS) fix data


\$--GGA,hhmmss.ss,llll.lll,a,yyyy.yyy,a,x,xx,x.x,x.x,M,x.x,M,x.x,xxxx*hh<CR><LF>



1. UTC of position
2. Latitude, N/S
3. Longitude, E/W
4. GPS quality indicator
5. Number of satellite in use,00-12, may be different from the number in view
6. Horizontal dilution of precision
7. Antenna altitude above/below
8. Unit of Antenna altitude, m
9. Geoidal separation
10. Unit of geoidal separation, m
11. Age of differential GPS data
12. Differential reference station ID, 0000-1023

RMC- Recommended minimum specific GPS/TRANSIT data


```
$--RMC,hhmmss.ss,A,llll.ll,a,yyyyy.yyy,a,x.x,x.x,xxxxxx,x.x,a,a,a*hh<CR><LF>
```



1. UTC of position fix
2. Status: A=data valid, V=navigation receiver warning
3. Latitude, N/S
4. Longitude, E/W
5. Speed over ground, knots
6. Course over ground, degrees true
7. Date: dd/mm/yy
8. Magnetic variation, degrees E/W
9. Mode indicator
10. Navigational status

ZDA - Time and date

```
$--ZDA,hhmmss.ss,xx,xx,xxxx,xx,xx*hh<CR><LF>
```



1. UTC
2. Day, 01 to 31 (UTC)
3. Month, 01 to 12 (UTC)
4. Year (UTC)
5. Local zone hours, 00h to ±14h
6. Local zone minutes, 00 to +59

APPENDIX IV INSTALLATION DRAWING


Drawing No.	Description
NGR3000-ID-001	NGR-3000 GNSS NAVIGATOR SYSTEM DIAGRAM
NGR3000-ID-002	NGR-3000 GNSS NAVIGATOR WIRING DIAGRAM
NGR3000-ID-003	NGR-3000 MAIN UNIT SIZE DRAWING
NGR3000-ID-004	NGR-3000 MAIN UNIT MOUNT DRAWING (TABLE TYPE)
NGR3000-ID-005	NGR-3000 MAIN UNIT MOUNT DRAWING (FLUSH TYPE)
NGR3000-ID-006	NGA100 GNSS ANTENNA SIZE & MOUNTING DRAWING

NGA100 GNSS ANTENNA



RG58/20M


ANTENNA



NGR-3000 GNSS NAVIGATOR

POWER SUPPLY DC24V

2X0.4




--- YARD SUPPLIED OR OPTIONAL


APPLICATION: NGR-3000 GNSS NAVIGATOR WIRING DIAGRAM

DATE	ITEM	SCALE	N/S	UNIT	REV	SIZE	A4
APPROVAL	CHECKED	DRAWING	DWG. NO.	NGR-3000-ID-3002			


NSR NEW SUNRISE CO., LTD.




FRONT VIEW



REAR VIEW



4-7X11 SLOT, FITTING HOLE






BOTTOM VIEW

NO.	DATE	REVISION & DESCRIPTION	CHECKED	SIGNATURE

APPLICATION: NGR-3000 MAIN UNIT SIZE DRAWING									
DATE	ITER	SCALE	UNIT	PROJ. NO.	DESIGNER	DRAWN	CHECKED	DATE	NO.
DRAWING NO.: NGR3000-ID-003									

NGA100 GNSS ANTENNA



NO.	DATE	REVISION & DESCRIPTION	CHECKED	DRAWING

APPLICATION: NGA100 ANTENNA SIZE & MOUNTING DRAWING									
DATE	ITER	SCALE	UNIT	PROJ. NO.	DATE	SCALE	UNIT	PROJ. NO.	DATE
APPROVAL	CHECKED	REVISION	DATE	SCALE	UNIT	PROJ. NO.	DATE	SCALE	UNIT
NGR3000-10-005									

Copyright by NEW SUNRISE CO., LTD. (NSR)

www.nsrmarine.com

info@nsrmarine.com

December, 2025