


# NHR-1500 Grounding

## 1. Antenna Coupler



Need to be connected with metal base through copper strip to ensure good grounding



Soldering to shield

Best



Soldering a screw

Good



Screw thread at hole

Normal




No Screw thread at hole

Bad

## Copper strip connection to vessel shield

## 2. Transceiver unit




Confirm the shield of cable to control unit is well grounding.

## 3. Control unit



#### 4. Printer



#### 5. NBDP terminal

