

1. Power on the device by pressing the [DIM] key and [UP] key simultaneously. First press the [F] key, then the [9] key to enter the menu setting mode.
2. Select the "MMSI INPUT" menu and press the [ENT] key to access the "MMSI INPUT" entry interface and start setting the MMSI code.
 - During the setting process, press the [ESC] key to cancel the setting and exit the "MMSI INPUT" entry interface. The "MMSI INPUT" menu will disappear after the setting is cancelled or completed.
3. Enter the MMSI code following the steps below:
 - Select the desired digit by pressing the [◀]/[▶] keys.
 - Press the [ENT] key to confirm the entered digit.
 - Move the cursor by selecting the "←" or "→" icon at the bottom left of the screen, then press the [ENT] key.
4. Repeat Step 3 to enter all 9 digits.
5. After entering all 9 digits, press the [F] key to confirm the input.
6. Re-enter the MMSI code for verification.
7. Press the [F] key to save the input digits. Repeat Steps 3 to 5 for this process.
8. Pressing the [ESC] key to cancel and exit the "MMSI INPUT" menu will clear the existing MMSI code.