


# How to Get VDR data and log file for APT&COC

Computer IP config


IP:172.16.8.175

MASK:255.255.0.0


Getway:172.16.8.1





Run VDRPlayer.




Click button "Download".





1. This table shows data has been recorded.
2. Select start time and end time of data to be downloaded. Normally 2 hours.
3. Select data destination, the data will be downloaded into.
4. Select data where download from, such as "LRU", "FFC" or "FPC".
5. Click button to download.





When downloading finished, there will be a folder like this.



Please compress the file “vdr” and send the compressed file(\*.rar \*.zip) with e-mail to [as@nsrmarine.com](mailto:as@nsrmarine.com) or upload the compressed file to NSR FTP server.