
SPECIFICATIONS

Product Name		ELECTRONIC CHART DISPLAY AND INFORMATION SYSTEM
Standards		IMO MSC.232(82), IMO A.694(17), IMO MSC.191(79), IEC 61174 Ed. 3,
		IEC 61162-1 Ed. 4, IEC 61162-2 Ed. 1, IEC 62288, IEC 60945 Ed. 4
Monitor Unit		24" wide color LCD, Full HD (1920 x 1080 pixels)
Chart Materials		IMO/IHO S57 edition-3 ENC vectorized material
		(IHO S-63 ENC data protection scheme),
		ARCS rasterized material, C-MAP and CM-93/3 vectorized
		materials (optional Jeppesen e-token required)
Display	True Motion	North-up, Course-up
Modes	Relative Motion	North-up, Course-up, Route-up, Heading-up
	Own Ship	Own ship's mark and numeral position in lat/lon, speed,
Data		course, etc.
Data Presentation	Target Tracking	Target information from AIS and TT
Presentation	(TT: ARPA, AIS)	(range, bearing, speed, course, CPA/TCPA)
	Cursor	EBL, VRM
Alarm Inform	ation	Waypoint, route monitoring and several alarms
		Navigation by result from external position sensor
		Dead reckoning with gyro and log
Position Calc	ulation	Data from gyro, log, and position sensors to be fed to
		mathematical filter to generate highly accurate position and speed
Navigation P	lanning	Planning by rhumb line, great circle
Route Monito	· ·	Off-track display, waypoint arrival alarm, shallow depth alarm
		User chart creation and display
User Chart		(up to 500 points for lines and symbols)
		Position, and other data at time of man overboard are recorded
MOB (Man C	verboard)	MOB mark is displayed on the screen
		1 port DVI-I for VDR
	DVI	1 port DVI-D for repeater display
		(Video signal is identical to the one output to the main display)
		2 ports, Ethernet 1000 Base-T
	LAN	(for interswitch network and sensor network)
	USB	6 ports, USB 2.0 type-A
Interface	000	2 ports, IEC61162-1/2
Internace		2 ports, IEC61162-1
	Serial I/O	Sentences: THS, HDT, GNS, GGA, RMC, GLL, VTG, VBW,
		VHW, DTM, WPL, RTE, DPT, DBT, CUR, VDR, MWV, ZDA,
		MTW, BOT, VDM, VDO, ALR, ETL, HTD, NRM, NRX, OSD,
		PRC, ROR, RPM, RSA, RSD, TRC, TRD, TTM, XDR, ABK
		FRO, ROR, REW, ROA, ROD, IRO, IRD, IIW, XDR, ABK

IN CONNECTION DU/

Radar input	2 ports
Ethernet	1 port

INTERCONNECTION DIAGRAM



* Please consult with your nearest distributors for details of the connectable analog Radar models. ** When flush-mounted, USB extender cable connector (1 m) can be used to connect with the USB cable of the USB devices (available in standard supply).

Nishinomiya, Hyogo, Japa www.furuno.com

Havant, Hampshire, U.K. www.furuno.co.uk

www.furunousa.

*** Up to three units of PCU-3000 can be incorporated into the network.

SENSOR ADAPTER

Control and Serial Input	LAN	1 port, Ethernet 100 Base-TX	
	Serial	8 ports, IEC 61162-1/2 (4 ports), IEC 61162-1 (4 ports)	
	Contact Closure	1 port for system fail, normal close or normal open	
Analog Input		3 ports/unit, -10 to +10V or 0 to 10V, 4 to 20 mA, selectable	
Digital Input		8 ports/unit, normal close or open, selectable	
Digital output		8 ports/unit, normal close or open, selectable	

POWER SUPPLY


/lain Unit	100-230 VAC 50/60 Hz (Primary), 24 VDC (Secondary)
Radar Connection Box	12 VDC/24 VDC
Sensor Adapter	24 VDC, 1.4 A

ENVIRONMENTAL CONDITION

Ambient Temperature	15°C to 155°C	
Relative Humidity	93 % or less at 40°C	
Degree of Protection	Panel PC	IP65 (front side)
		IP22 (back side)
	Trackball Control Unit	IP22
	Radar Connection Box	IP22
Vibration	IEC 60945 Ed. 4	

EQUIPMENT LIST

Standard						
1	Panel Computer Unit PCU-3000	1 unit				
2	Trackball Control Unit RCU-030	1 unit				
3	Standard spare parts, installation materials and accessories,					
	incl. ENC dongle*	1 set				
	* Jeppesen e-token is not included.					
Optio	on					
1	Sensor Adapter	1 set				
	MC-3000S Control Serial					
	MC-3010A Analog					
	MC-3020D Digital IN					
	MC-3030D Digital OUT					
2	Switching Hub HUB-100 for sensor network	1 unit				
3	Intelligent Hub HUB-3000 for interswitch network	1 unit				
4	Radar Connection Box RCB-002 for interface with 3rd party rad	ar 1 unit				
5	Mounting bracket for table-top mount	1 unit				
6	Cable Clamp for PCU-3000	1set				
7	USB Keyboard	1 unit				
8	Fixing Bracket for RCU-030	1 set				



Electronic Chart Display and Information System



with an optional keyboard

FURUNO ELECTRIC CO., LTD. FURUNO ESPAÑA S.A. Nishinomiya, Hyogo, Japan Madrid, Spain www.furuno.es FURUNO U.S.A., INC. FURUNO DANMARK A/S Camas, Washington, U.S.A. Hvidovre, Denmark www.furuno.dk FURUNO (UK) LIMITED FURUNO NORGE A/S Ålesund No www.furun FURUNO FRANCE S.A.S. FURUNO SVERIGE AB Bordeaux-Mérignac, France www.furuno.fr Västra Frölunda, Swede www.furuno.se

FURUNO FINLAND OY Espoo, Finland vww.furuno.fi FURUNO POLSKA Sp. Z o.o. Gdvnia, Poland www.furuno.pl FURUNO EURUS LLC St. Petersburg, Russian RICO (PTE) LTD Singapore www.rico.com.sg

FURUNO DEUTSCHLAND GmbH Rellingen, German www.furuno.de FURUNO HELLAS S.A. Piraeus, Gree www.furuno.ar FURUNO (CYPRUS) LTD Limassol, Cyprus www.furuno.com.cy FURUNO KOREA CO., LTD. Busan, Korea

13103SK Printed in Japan Catalogue No. M-1559





Model: FMD-3100 (with 24" wide LCD)

www.furuno.com



24" wide LCD (Full HD: 1920 x 1080 pixels)



with an optional keyboard

Electronic Chart Display and Information System

navigation to electronic navigation

Model: FMD-3100 (with 24" wide LCD)

- Streamlined integration into the onboard navigation system; perfectly suited for ECDIS retrofitting projects
- 2 LAN ports and 4 serial ports are available to facilitate smooth integration into a bridge network as well as interface with onboard navigation sensors
- Flexibility in installation; supporting both table-top mounting* as well as flush-mounting to match the space availability in the wheelhouse
 *Optional mounting bracket for table-top mounting required.



Mounting Bracket for table-top mounting

Suitable for both primary and back-up ECDIS

Dual configuration of the FMD-3100 supports the vessel to go paperless. For those who have already installed the FMD-3200/FMD-3300 onboard the vessel, the FMD-3100 can be used as a cost-effective back-up arrangement for the FMD-3200/FMD-3300 ECDIS.

Easily interfaces with existing FAR-2xx7 series Radar for:


- Radar overlay
 Route and waypoint
- Target track info
 User Charts

exchange via Ethernet

*for Radar overlay with analog Radar such as FAR-2xx5 series, the optional RCB-002 Radar Connection Box is required.

Complies with the following IMO and IEC regulations:

• IMO MSC.232(82) • IEC 61162-1 Ed. 4 • IEC 61174 Ed. 3 • IMO A.694(17) • IEC 61162-2 Ed. 1 • IEC 62288 Instantaneous chart redraw delivered by FURUNO's advanced chart drawing engine, making redraw latency a thing of the past



Instantaneous chart redraw

Task-based operation realized by combination of Status bar and InstantAccess bar providing quick access to the needed tasks/functions

The user interface of the FMD-3100 centers on carefully organized operational tools: Status bar and InstantAccess bar. The Status bar contains information about the operating status, and the InstantAccess bar contains all the tasks available. These operational tools deliver straightforward, task-based operation by which the operator can quickly perform navigational tasks without having to go deeper into an intricate menu tree.





Drop-down menu to facilitate streamlined operation


on the buttons in the Status bar and InstantAccess bar indicates that there are hidden options of actions/tasks to be performed in the sub-layer, which can be initiated by left-clicking the buttons. This way, the operator can quickly gain access to the related tasks.

Compatible cartography

- IHO/S-57 Edition 3 vector chart (IHO S-63 data protection scheme)
 Admiralty Vector Chart Service by UKHO
 C-MAP ENC*
- Jeppesen Primar ECDIS Service*
- ARCS raster chart
- C-MAP Professional+**


*Jeppesen e-token is not included in the standard supply. **C-MAP Professional+ is a private chart, hence not construed as replacement for paper chart.

- Interface with Jeppesen Dynamic Licensing Service available
- Compatibility with Admiralty Information Overlay (AIO) for further navigation safety



Additional AIO layer includes all Admiralty Temporary and Preliminary Notices to Mariners as well as additional ENC Preliminary Notices to Mariners, i.e., reported navigational hazards that

Mariners, i.e., reported navigational hazards that have been incorporated into a paper chart, but have yet to be included in ENCs. The service is free of charge as part of Admiralty Vector Chart Service (AVCS) by UKHO.



A solution to support sm ooth transition from paper-based



Electronic Navigation Chart (ENC)



Place the cursor on the AIO object and right-click to open the contextual menu. Select "Object INFO" to open the chart object window.

Chart object window

On the chart object window, select the AIO object and click "OK" to view the details.





Raster Navigation Chart (RNC)



The full text of the Notice to Mariners as well as associated diagrams can be displayed subsequently.